

How to use a simple weaving jigs.

1. First position the right hand jig to the right of the area you desire to put the pattern.



2. Then wrap masking tape to the left of the area you want the pattern and reverse the tape so the sticky surface is on the outside.



3. Now place thread on tape and load into right hand jig until layer is complete. Repeat if there are more than one layer. When all thread is in right hand jig then set left hand jig on rod.



4. Anchor threads with about 1/2" of flat wrap then begin weave. Pictures show progression of weave.



If you have any questions please feel free to contact me at

Doc Ski Rods
2271 Mariposa Dr.
Oxnard, Ca. 93036

Email docski377@aol.com

Happy Weaving